Removal

- 1 Remove windshield pane (67-100).
- 2 Push the three covers on ornamental frame aside.
- 3 Push ornamental frame out of rubber frame by means of plastic wedge.

Installation

Note: Rub rubber frame lightly with acid-free grease prior to installing ornamental frame.

4 For installation proceed vice versa.